

Uniden®

SSE 30 **Corded Telephone**

For more exciting new products please visit our website:
Australia: www.uniden.com.au

OWNER'S MANUAL

Important Safety Instructions

- This unit is **NOT waterproof**. DO NOT expose this unit to rain or moisture.
- Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use the telephone to report a gas leak in the vicinity of the leak.

SAVE THESE INSTRUCTIONS!

What's in the Box?



- If any item is missing or damaged, contact your place of purchase immediately. Never use damaged products!
- Need help? Get answers at our website:
www.uniden.com.au for Australian model.

Installing Your Phone

Connect the Corded Handset


1. Use the coiled cord to connect the corded handset to the connector on the bottom of the base.
2. Connect the the telephone cord to the TEL LINE jack and plug the other end to a standard telephone wall socket.


Test the Connection

Pick up the corded handset from the base. You should hear a dial tone. When you get a dial tone, make a quick test call.


Wall Mount Installation

You can mount the SSE 30 on the wall.




-  **To prevent the handset from falling out of the cradle, while the phone is hanging on the wall, you must reverse the hook. Please refer to the image below.**



1. Push the handset hook up and out of the slot on the base with your thumb, rotate the hook 180°, and replace it back on the slot.
2. Slip the mounting holes, located at the back of the base, over the screw heads and firmly slide down to secure into place.



Handset & Base Callouts



Operation

Answer a Call

When there is an incoming call, the phone rings and the ringer LED flashes. Pick up the handset to answer the call. After talking, hang up the handset or press RESET to end the call.

Boost and Volume Control

The BOOST button helps you control the volume of the receiver. During a conversation, press the BOOST button (the ringer LED will glow) and then rotate the Volume Control to adjust the volume according to your liking.

Last Number Redial

Pick up the handset and press REDIAL, the phone will automatically dial out the last dialed number.

Mute

During a call, press and hold MUTE to mute the microphone.

Flash

Call Waiting is a service that is available from your telephone service provider. If you have opted for this service from your provider, then press FLASH and 2 to put the first caller on hold and accept the waiting call. To return to the original caller, press FLASH and 2 again.

Ringer

Slide the Ringer switch to OFF, to mute the ringer, which means that the phone will not ring for any calls. However, the ringer LED will flash, indicating an incoming call.

Important Information

Solving Problems

Listed below are some of the problems and the possible solutions. If you still need help, visit our website, listed on the front cover.

General Problems	Possible Solutions
No dial tone	Press and release the hook switch.
Phone doesn't ring	Make sure the Ringer switch is turned on.
Other party cannot hear you	Make sure the telephone cord is securely plugged in.

ONE-YEAR LIMITED WARRANTY

SSE 30

IMPORTANT Satisfactory evidence of the original purchase is required for warranty service Please refer to our Uniden website for any details or warranty durations offered in addition to those contained below.

Warrantor

The warrantor is Uniden Australia Pty Limited ABN 58 001 865 498 (“Uniden Aust”).

Terms of Warranty

Uniden Aust warrants to the original retail purchaser only that the SSE30 (“the Product”), will be free from defects in materials and craftsmanship for the duration of the warranty period, subject to the limitations and exclusions set out below.

Warranty Period

This warranty to the original retail purchaser is only valid in the original country of purchase for a Product first purchased either in Australia or New Zealand and will expire one (1) year from the date of the original retail sale. If a warranty claim is made, this warranty will not apply if the Product is found by Uniden to be:

- (A) Damaged or not maintained in a reasonable manner or as recommended in the relevant Uniden Owner’s Manual;
- (B) Modified, altered or used as part of any conversion kits, subassemblies or any configurations not sold by Uniden Aust;
- (C) Improperly installed contrary to instructions contained in the relevant Owner’s Manual
- (D) Repaired by someone other than an authorized Uniden Repair Agent in relation to a defect or malfunction covered by this warranty; or
- (E) Used in conjunction with any equipment, parts or a system not manufactured by Uniden.

Parts Covered

This warranty covers the Product and included accessories.

User-generated Data

This warranty does not cover any claimed loss of or damage to user-generated data (including but without limitation phone numbers, addresses and images) that may be stored on your Product.

Statement of Remedy

If the Product is found not to conform to this warranty as stated above, the Warrantor, at its discretion, will either repair the defect or replace the Product without any charge for parts or service. This warranty does not include any reimbursement or payment of any consequential damages claimed to arise from a Product's failure to comply with the warranty.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is in addition to and sits alongside your rights under either the COMPETITION AND CONSUMER ACT 2010 (Australia) or the CONSUMER GUARANTEES ACT (New Zealand) as the case may be, none of which can be excluded.

Procedure for Obtaining Warranty Service

Depending on the country in which the Product was first purchased, if you believe that your Product does not conform with this warranty, you should deliver the Product, together with satisfactory evidence of your original purchase (such as a legible copy of the sales docket) to Uniden. Please refer to the Uniden website for address details. You should contact Uniden regarding any compensation that may be payable for your expenses incurred in making a warranty claim. Prior to delivery, we recommend that you make a backup copy of any phone numbers, images or other data stored on your Product, in case it is lost or damaged during warranty service.

UNIDEN AUSTRALIA PTY LTD

Phone number: 1300 366 895

Email address: custservice@uniden.com.au

Uniden

Uniden Australia Pty Ltd
Printed in China