

Start Here!

UBCD536-PT

Quick Start Guide



About the Owner's Manual

The UBCD536-PT is designed for the Australian and New Zealand market.

The UBCD536-PT Owner's Manual is presented in hard copy in the box or can be downloaded as a PDF document from www.uniden.com.au

The warranty for the UBCD536-PT is presented on side 2 of this guide and at the back of the Owner's Manual.

Step 1 - Check the Package Contents

Make sure your scanner's packaging includes the following items.

1x UBCD536-PT
1x USB Connection Cable
1x AC Power Adaptor
1x DC Power Adaptor
1x DC Cord with Orange Wire
1x microSD card (installed)
1x Mounting Bracket with screw and foot
1x Telescopic Antenna

If any of these items are damaged or missing contact your place of purchase!

Step 2 - Connect the Antenna

Attach the antenna to the unit.

WARNING: Dropping the unit may damage or break the antenna.

Note: After market antennas (not supplied) are available which may provide increased reception.

Step 3 - Power Up the Unit

Plug the AC adapter into the unit.

Plug the other end of the adaptor into a standard 240V AC power outlet.

Step 4 - Turning On Your Scanner

Turn Power/VOL knob to turn on the scanner. At initial power up, you will see this screen.

Welcome to UBCD536-PT

**Please set the clock.
(Press [E])**

Turn the Scroll Control Knob or press number buttons to change the value of each field. When you are satisfied with the setting, press Enter (**E yes**)



BASIC OPERATION

1. Turning On the Scanner and adjusting the Volume.
To turn the scanner on, rotate Power/VOL clockwise. Turn the knob to a comfortable sound level.
2. Setting the Squelch
Rotate the SQ knob clockwise until you either hear a broadcast or noise just stops. The control is now set for strong signals. If you desire to hear a weaker signal, turn it counter clockwise from that point until you hear background noise once more.

SCANNING

What is it?

Scanning is the automatic monitoring of a bank of radio frequency channels. When an active channel is found the radio pauses to listen.

Scan groups are arranged by CFA District and pre-programmed into favorite list. District scan groups contain a mixture of RMR Trunk talk groups for Dispatch service (RRDS), Command and Control purpose (RMR CC), Analog Conventional and P25 Digital conventional channels.

Favorite list numbers are referred to by CFA's channel number on the District worksheets.

When you turn on your scanner, "Nothing to Scan" appears on the display.

a) Press "0" and "2" then press Enter (**E yes**) to turn ON.

b) To turn the other District Scan group ON, select District group number then press Enter (**E yes**)

Favorite List Number (Example)

"F0: 2" means scanning District-02 Scan group.
"F2: 4" means scanning District-24 Scan group.

Scanning CH information

- Conventional/Trunk
- Department/Site Name.
- Channel Name

F0: -- 2 ----- 17 : 23
S0: ----- District 02

D02 Trunk
CFA Dispatch
RMR 502

Unavoid CH of Frequency/Talkgroup

1. Press CHANNEL (**CHANNEL**) to hold mode.
2. Turn the scroll control until you reach the channel you want to unavail ("AVOID" appear in the display).
3. Press AVOID (**AVOID**) to set unavail ("AVOID" disappears from the display).
4. Press CHANNEL (**CHANNEL**) back to scan mode.


Avoid CH of Frequency/Talkgroup

1. Press CHANNEL (**CHANNEL**) to hold mode.
 2. Turn the scroll control until you reach the channel you want to avoid.
 3. Press AVOID (**AVOID**) TWICE to permanently avoid ("AVOID" appears in the display).
- *If you press AVOID, only ONCE that channel would be avoided only temporarily. This gets cancelled when you cycle power.
4. Press CHANNEL (**CHANNEL**) back to scan mode.

Resetting the Scanner

You can perform a factory reset by following the steps below.

1. Press MENU then turn the Scroll Control Knob to "Settings" and press the Knob.
2. Turn the Scroll Control Knob to "Initialize Setting" and press the Knob.
3. Press Enter button (**E yes**).



WARNING! Resetting the scanner clears all data and settings you have entered.

ONE YEAR LIMITED WARRANTY

IMPORTANT Satisfactory evidence of the original purchase is required for warranty service Please refer to our Uniden website for any details or warranty durations offered in addition to those contained below.

Warrantor

The warrantor is Uniden Australia Pty Limited ABN 58 001 865 498 ("Uniden Aust").

Terms of Warranty

Uniden Aust warrants to the original retail purchaser only that the UBCD536-PT("the Product"), will be free from defects in materials and craftsmanship for the duration of the warranty period, subject to the limitations and exclusions set out below.

Warranty Period

This warranty to the original retail purchaser is only valid in the original country of purchase for a Product first purchased either in Australia or New Zealand and will expire one (1) year from the date of the original retail sale.

If a warranty claim is made, this warranty will not apply if the Product is found by Uniden to be:

- (A) Damaged or not maintained in a reasonable manner or as recommended in the relevant Uniden Owner's Manual;
- (B) Modified, altered or used as part of any conversion kits, subassemblies or any configurations not sold by Uniden Aust;
- (C) Improperly installed contrary to instructions contained in the relevant Owner's Manual
- (D) Repaired by someone other than an authorized Uniden Repair Agent in relation to a defect or malfunction covered by this warranty; or
- (E) Used in conjunction with any equipment, parts or a system not manufactured by Uniden.

Parts Covered

This warranty covers the Product and included accessories.

User-generated Data

This warranty does not cover any claimed loss of or damage to user-generated data (including but without limitation phone numbers, addresses and images) that may be stored on your Product.

Statement of Remedy

If the Product is found not to conform to this warranty as stated above, the Warrantor, at its discretion, will either repair the defect or replace the Product without any charge for parts or service. This warranty does not include any reimbursement or payment of any consequential damages claimed to arise from a Product's failure to comply with the warranty.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is in addition to and sits alongside your rights under either the COMPETITION AND CONSUMER ACT 2010 (Australia) or the CONSUMER GUARANTEES ACT (New Zealand) as the case may be, none of which can be excluded.

Procedure for Obtaining Warranty Service

Depending on the country in which the Product was first purchased, if you believe that your Product does not conform with this warranty, you should deliver the Product, together with satisfactory evidence of your original purchase (such as a legible copy of the sales docket) to Uniden. Please refer to the Uniden website for address details. You should contact Uniden regarding any compensation that may be payable for your expenses incurred in making a warranty claim. Prior to delivery, we recommend that you make a backup copy of any phone numbers, images or other data stored on your Product, in case it is lost or damaged during warranty service.

UNIDEN AUSTRALIA PTY LTD

Phone number: 1300 366 895

Email: custservice@uniden.com.au

PACIFIC TELECOMMUNICATIONS

Service Department

180 Plenty Road

Preston, VIC 3072

Phone number: 03 9480 5700

Email: service@pac-tel.com.au

www.uniden.com.au

U69UB375AZZ(0)

Uniden[®]