

Uniden®

Elite 9105

Accessory Handset

For more exciting new products please visit our website:

Australia: www.uniden.com.au


New Zealand: www.uniden.co.nz

OWNER'S MANUAL


Elite 9105 Accessory Handset Owner's Manual

What's in the box?

Elite 9105 accessory
handset and
charger




AC adapter
(AAD-600S(M))



Rechargeable
battery pack
(BT-694 or BT-694s)

Battery
cover



• If any items are missing or damaged, contact your place of purchase immediately. Never use damaged products!

Need Help? Get answers at our website:

www.uniden.com.au for Australian model or

www.uniden.co.nz for New Zealand model.

Important Safety Instructions!


When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:


- **This unit is NOT waterproof.** DO NOT expose this unit to rain or moisture.
- Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
- Do not use the telephone to report a gas leak in the vicinity of the leak.
- Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
- Do not place the handset in any charging cradle without the battery installed and the battery cover securely in place.

SAVE THESE INSTRUCTIONS!

INSTALLING YOUR HANDSET

Charge the Battery

1. Unpack the handset, battery pack, and battery cover. If you need to remove the cover, press in on the notch and slide the cover down and off.
 2. Line up the battery connector with the jack inside the handset; the connector only fits one way.
 3. Push the connector in until it clicks into place; tug gently on the wires to make sure the battery is securely connected.
 4. Replace the battery cover and slide it into place.
 5. Use the AC adapter to connect the power jack on the charger to a regular indoor (240V AC) power outlet.
 6. Place the handset in the charger with the display facing forward. If the display doesn't light up, reset the handset or connect the charger to a different outlet.
-  **Charge the handset completely (about 15 hours) before using it.**



REGISTERING TO A BASE

- ✎ **The accessory handset won't work until you register it to a base!**

Compatible Bases

This handset is designed for use with Uniden's Elite 9135 and Elite 9145 bases. For the most up-to-date list of which bases this handset is compatible with, see our website.

Registration Methods

Does the handset fit in the base cradle?

Yes Place the handset in the base. The display should say *Registering*.

No Does the base have an LCD display?

Yes 1. On the base, open the menu and select *Register Accy*.

2. On the handset, press and hold # until the handset display says *Registering* (about 2 seconds).

No 1. On the base, press and hold FIND when the phone is in standby (about 5 seconds).

2. On the handset, press and hold # until the handset display says *Registering* (about 2 seconds).

- ✎ **After about 30 seconds, the handset display should say *Registration Complete*.**

Test the connection

Pick up the handset and press HOME/FLASH. Make sure you get a dial tone. (Press END to hang up.)

If...	Try...
<ul style="list-style-type: none">• you don't hear a dial tone• the display says <i>Registration Failed</i>	Making sure the handset is fully charged, then trying again.

IMPORTANT INFORMATION

- All features and operation for the handset are described in the user's guide for one of the bases listed under the *Compatible Bases* section.
- User guides for all Uniden phones are available on our website for free downloading.

AC Adapter and Battery Information

AC Adapter	Part number	Input Voltage	Output Voltage
	AAD-600S(M)	240V AC, 50 Hz	9V DC@ 210mA
Battery pack	Part number	Capacity	
	BT-694s or BT-694s	650mAh (BT-694) or 500mAh (BT-694s)	

- Use only the supplied AC adapters.
- Use the proper adapter for the base & any chargers.
- Do not place the unit in direct sunlight or subject it to high temperatures.
- Replace the battery when the talk or standby time becomes noticeably reduced. For replacements, visit the online shop on our website.
- When the battery gets low, the handset beeps and shows a low battery alert; put the handset in the cradle for recharging.

Rechargeable Nickel-Metal-Hydride Battery Warning

CAUTION! Risk of explosion if battery is replaced by an incorrect type!

Dispose of used batteries according to the instructions.

Do not open or mutilate the battery.

Disconnect the battery before shipping this product.

- This equipment contains a rechargeable Nickel-Metal-Hydride (Ni-MH) battery.
- Do not short-circuit the battery.
- The batteries in this equipment may explode if disposed of in a fire.
- Do not charge the batteries in any charger other than the one specified in the owner's manual. Using another charger may damage the battery or cause it to explode.

Rechargeable batteries must be recycled or disposed of properly. Uniden works to reduce lead content in PVC coated cords in our products and accessories.

ONE-YEAR LIMITED WARRANTY

UNIDEN Elite 9105

IMPORTANT Satisfactory evidence of the original purchase is required for warranty service

Please refer to our Uniden website for any details or warranty durations offered in addition to those contained below.

Warrantor

The warrantor is either Uniden Australia Pty Limited ABN 58 001 865 498 ("Uniden Aust") or Uniden New Zealand Limited ("Uniden NZ") as the case may be.

Terms of Warranty

Uniden Aust/NZ warrants to the original retail purchaser only that the Elite 9105 ("the Product"), will be free from defects in materials and craftsmanship for the duration of the warranty period, subject to the limitations and exclusions set out below.

Warranty Period

This warranty to the original retail purchaser is only valid in the original country of purchase for a Product first purchased either in Australia or New Zealand and will expire one (1) year from the date of the original retail sale.

If a warranty claim is made, this warranty will not apply if the Product is found by Uniden to be:

- (A) Damaged or not maintained in a reasonable manner or as recommended in the relevant Uniden Owner's Manual;

- (B) Modified, altered or used as part of any conversion kits, subassemblies or any configurations not sold by Uniden Aust or Uniden NZ;
- (C) Improperly installed contrary to instructions contained in the relevant Owner's Manual
- (D) Repaired by someone other than an authorized Uniden Repair Agent in relation to a defect or malfunction covered by this warranty; or
- (E) Used in conjunction with any equipment, parts or a system not manufactured by Uniden.

Parts Covered

This warranty covers the Product and included accessories.

User-generated Data

This warranty does not cover any claimed loss of or damage to user-generated data (including but without limitation phone numbers, addresses and images) that may be stored on your Product.

Statement of Remedy

If the Product is found not to conform to this warranty as stated above, the Warrantor, at its discretion, will either repair the defect or replace the Product without any charge for parts or service. This warranty does not include any reimbursement or payment of any consequential damages claimed to arise from a Product's failure to comply with the warranty.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

This warranty is in addition to and sits alongside your rights under either the COMPETITION AND CONSUMER ACT 2010 (Australia) or the CONSUMER GUARANTEES ACT (New Zealand) as the case may be, none of which can be excluded.

Procedure for Obtaining Warranty Service

Depending on the country in which the Product was first purchased, if you believe that your Product does not conform with this warranty, you should deliver the Product, together with satisfactory evidence of your original purchase (such as a legible copy of the sales docket) to Uniden at the addresses shown below. You should contact Uniden regarding any compensation that may be payable for your expenses incurred in making a warranty claim. Prior to delivery, we recommend that you make a backup copy of any phone numbers, images or other data stored on your Product, in case it is lost or damaged during warranty service.

UNIDEN AUSTRALIA PTY LTD

Service Division
345 Princes Highway,
Rockdale, NSW 2216
Phone number: 1300 366 895
Email address: custservice@uniden.com.au

UNIDEN NEW ZEALAND LTD

Service Division
150 Harris Road, East Tamaki
Auckland 2013
Phone number: (09) 273 8377
Email address: service@uniden.co.nz

Uniden[®]

© 2011 Uniden Australia Pty Ltd/Uniden New Zealand Limited
Printed in Vietnam U01UU244BZA(0)